




# Activision Guitar Hero Live Guitar Controller Whammy Bar Replacement

Whammy Bar not responding properly.

Written By: Zachery



## INTRODUCTION

How to remove the Whammy Bar and its components for replacement/repair.


---



### TOOLS:


- [Phillips #00 Screwdriver](#) (1)
  - [.25" Flathead Screwdriver](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Casing




- The first thing we want to do is remove the neck from the body. This is necessary to access either the inside of the neck or the body.
  - The round tab with a triangle can be turned by inserting a .25" tip Flathead screwdriver and turning. Simultaneously, as the tab turns about a quarter circle, pull the neck and it should slide out with minimal force.
  - Once the neck has been separated from the body remove the eight screws from the back of the neck with a Phillips Head 0 screwdriver. All screws are 12 mm.
  - Next remove the four screws that were covered by the neck.
  - Finally, remove the eight screws from the back of the body. With all the screws out, both the neck and the body shells should open with minimal force.
- ⚠ When separating the front and back half of the body do so carefully as the wiring from the battery pack to the components is fixed to each half with adhesive and can detach from any of the points if pulled to roughly.

## Step 2



- These are the whammy bar components, we highly recommend removing these components before working on other areas of the body as the whammy bar protrudes making it difficult to rest on a flat surface.
- To remove the whammy bar, follow the steps included in the whammy bar replacement guide, found on our device.



## Step 3 — Whammy Bar



- After opening the controller carefully remove the piece of plastic connected to the strip of wire as shown in the photo.
- ⓘ After the piece of plastic which connects to the wire has been removed, set it aside where it won't be damaged.




## Step 4



- Carefully remove the cylinder-shaped lid, by pulling outwards on the piece, it will slide out easily.
- ⓘ There should be a click when the piece has disconnected, then slowly slide part out and store safely.

## Step 5



- Grab the Whammy Bar by the base of the component, and gently lift to remove the bar.
- ⓘ There won't be anything holding the Whammy Bar in place at this point, so if you feel any tension something may be caught on the Whammy Bar.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-25 11:59:01 AM.